

SolarGuard™ Multi-zone Control Panel Upgrade

Use this control panel to fully upgrade your SolarGuard system. It allows you to maintain full control over system operation monitoring each one of the detectors providing numerous additional features.



- Compatible with the SolarGuard SG1100ARM2 system
- Adds part arm feature
- Entry and exit warning countdown beeps
- Zone activation LEDs
- Low battery warning for each zone
- Adds a loud internal siren to your system
- Programmable frequency jamming warning
- Automatically sends a unique digital code to your SolarGuard bellbox on activation
- Expansion connectors for adding: wired sirens, strobes, tamper or panic buttons and autodiallers

Summary

The multi-zone control panel can be used to form the heart of your existing SolarGuard wirefree home security system allowing you full control via the keypad and an easy means of monitoring the status of the system with individual zone indications

Entry and Exit countdown beeping will warn you that the system is ready to activate both built-in sirens and any wired or wirefree sirens you may also be operating

Specifications

Power Supply	12V AC Mains Adaptor (Supplied)
Security Code	4 Digit - 10000 Combinations
Site Code	9 Bit - 512 Combinations
Battery Backup	8 x 1.2V Ni Cad AA Size
Range	Average 15 to 25 metres
Frequency	418MHz
Zones	Entry/Exit, Walkthrough, 2 x Instant, 24 Hour
Internal Sounder Volume	110dB